

PROVIDED:



TOOLS YOU MAY NEED:



NOTES:



OAKSTORE
HAND CRAFTED OAK FURNITURE

Oak Store Direct
Units 4-6
Station Road, Shipley
West Yorkshire, BD18 2JL

sales@oakstoredirect.com
www.oakstoredirect.com



OAKSTORE
HAND CRAFTED OAK FURNITURE



INSTALLATION GUIDE
WALL SHELF FIXINGS





1

Use the spirit level to mark a level line at the required point of installation.



2

Use the tape measure and measure across all the hole centres



3

Transfer measurements across to the line on the wall for each centre point.



4

Now mark on the wall for each bracket hole (for modern brackets allow for the keyhole when marking out)



5

Use the masonry drill with a 7mm masonry or SDS bit, and drill to a depth of 75mm, (you can use masking tape as a depth gauge)



6

Insert the 7mm rawl plugs provided and if required use the hammer to ensure the plugs are flush.



7

Use a pozi driver or cordless drill and fix each bracket to the wall just hand tight for now using wall screws



8

Place the spirit level onto the shelf and check for level, make any adjustments by tapping the brackets before fastening screws tight.



9

Place the shelf on the brackets and final check for level



10

Bracket shelves can be secured using screws or double sided tape (not provided)

WALL BRACKETS

This guide can be use to install the following wall brackets:

Traditional (oak wall bracket)

Modern (oak wall bracket)

Chrome (wall bracket)

Usage:

Modern: 10kg per bracket

Traditional: 10kg per bracket

Chrome: 15kg per bracket

For more information visit our website or email us:

sales@oakstoredirect.com